

Bitte Beachten! Attention! Attenzione!

Der Demo-Film startet 15 Sek. nach dem Einschalten!

Zum Abschalten des Demo-Modus und des Films befolgen Sie die Anweisungen:

Gerät einschalten

Drücken Sie den Softkey „Gerät“

Wählen Sie in diesem Menu den Punkt „Demonstration Mode“ durch bewegen (hoch/runter) des Joystick und bestätigen Sie dies mit „Enter“ durch drücken auf den Joystick.

Sie gelangen in das Menu „Start Demo“ und wählen die weiteren Möglichkeiten mit „Enter“.

Bewegen Sie den Joystick, bis die gewünschte Einstellung erscheint (z.B. nie) und bestätigen Sie dies durch Drücken der Taste „Speichern“.

Der automatische Film-Modus ist nun ausgeschaltet.

The demo movie starts 15 sec. after switching on the device!

To Switch off the auto starting movie please follow the steps below:

Switch on GIGA Vu PRO

Press the button labelled “Device” in the lower right-hand corner

Select menu option “Demonstration mode” by moving the joystick up and down and select the option by pressing the joystick.

Enter the menu “Start demo” by pushing the joystick to the right and select the options by scrolling up and down with the joystick.

Confirm the selection you would prefer (“Never” for example) and confirm it by pushing the “Save” button in the lower right-hand corner.